

Down & Out™

Panel Blind

INSTRUCTIONS

WARNINGS

- For your safety be sure to read all instructions carefully.
- This hunting blind uses fire resistant material. This material is not flame proof.
- Do not allow open flames or other sources of ignition to come in contact with the material of this hunting blind.
- Do not use a heater in the blind. Unvented fumes can cause sickness or death.
- Do not shoot a firearm through the shoot through screens. The muzzle flash could ignite the screen material.
- Do not use expandable broadheads with shoot through screens. The blades may open prematurely. Use fixed blade broadheads only.
- Do not allow children to play with this blind without adult supervision.

CONTENTS

- EZ Fit Case
- Hunting Blind
- Instruction Sheet
- Ground Stake Bag
- (6) Ground Stakes

SETUP UP INSTRUCTIONS



STEP 1: Remove from EZ Fit case.



STEP 2: Un-fold the accordion style panel folding frame and situate into a hexagonal shape. Attach the two ends with the integrated straps.



STEP 3: Insert the powder coated steel struts through the designated holes in the frame.



STEP 4: Attach the roof over the struts.

TAKE DOWN INSTRUCTIONS



STEP 1: Detach and remove roof from struts.



STEP 2: Remove struts from frame.



STEP 3: Unattach the straps on end panels.
Fold panels in an accordion style pattern




STEP 4: Place in EZ Fit Case.

⚠ WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov. WASH HANDS AFTER USE. **WAIVER OF LIABILITY:** Use only as intended. The manufacturer assumes no responsibility for injury, damage or loss arising from the use of this product howsoever caused.

⚠ WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC. This tent meets the flammability requirements of CPAI - 84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

**Blind must never be packed while damp, as mildew will form within a few days.
Allow to dry completely before collapsing and storing blind.**



HAWKHUNTING.COM

MANUFACTURED BY:
GSM, LLC.
P.O. BOX 535189
GRAND PRAIRIE, TX 75053
TOLL FREE: 877-269-8490